

Residential Rooftop Installation

1. Site survey

Confirm roof pitch, orientation, shading, and structural load capacity before mounting.

2. Mount the rail

Fix aluminium rail to rafters at marked spacing using the supplied flashed hooks.

3. Place the panels

Set panels onto the rail and secure with mid and end clamps torqued to spec.

4. Wire the string

Connect panels in series with MC4 connectors, then route DC cable to the inverter.

5. Commission

Power up the inverter, confirm production on the monitoring app, and log the install.